A large, stylized, light gray illustration of a goose in flight, serving as a background for the title. The goose is shown from a side profile, with its wings spread wide and its head turned back. The illustration is detailed, showing the texture of the feathers.

NEW TRUCK CAMPER OWNER'S MANUAL

Table of Contents

| | |
|--|-------------------|
| <i>Introduction</i> | <i>Page 1</i> |
| <i>Warranty</i> | <i>Page 2-3</i> |
| <i>Loading Truck Camper</i> | <i>Page 4-5</i> |
| <i>Wiring 7 way plug</i> | <i>Page 6</i> |
| <i>Raising and Lowering Camper</i> | <i>Page 7</i> |
| <i>Camper Storage</i> | <i>Page 8</i> |
| <i>Camping off Truck</i> | <i>Page 8</i> |
| <i>Before moving Camper</i> | <i>Page 9</i> |
| <i>Systems</i> | <i>Page 10-11</i> |
| <i>Plumbing System</i> | <i>Page 12-13</i> |
| <i>Electrical System</i> | <i>Page 14</i> |
| <i>Safety System</i> | <i>Page 15</i> |
| <i>Awnings</i> | <i>Page 16</i> |
| <i>Camper Maintenance</i> | <i>Page 17-18</i> |
| <i>Winterizing Procedures 10-2 EX Dry & Wet</i> | <i>Page 19-26</i> |
| <i>Winterizing Procedure 9-6 Wet Bath & 8-11</i> | |
| <i>EX Dry & Wet Bath</i> | <i>Page 27-36</i> |

Introduction:

Welcome to the Northern Lite family, we would like to thank you for choosing one of our high quality truck campers. This manual is designed to help you with the different systems in your camper in conjunction with the supplied manuals from the appliance and equipment manufacturers that we have included in the black pouch.

Your dealer also should provide you with a full walk through of all the systems but we understand sometimes it is a lot of information. If you have any questions, problems or concerns please contact your selling dealer. If they are not able to answer your inquiries please feel free to contact the factory directly.

Owner's Responsibility

As the new owner of a Northern Lite truck camper it is important to read this manual and all appliance manuals for safe and proper operation of your new unit.

Dealers Responsibility

It is the dealer's responsibility to complete a full pre delivery inspection prior to you picking up your new unit. Also they will complete a familiarizing of the camper and complete warranty registration.

Please read these entire manual and supplemental suppliers manuals before using or loading your Northern Lite truck camper.

Warranty

Northern Lite Mfg. LP New Recreational Vehicle Warranty

Northern Lite Mfg. LP herein after called the Manufacturer, hereby warrants that the selling dealer, or the manufacturer will repair, replace or adjust any parts, except those parts and components which are covered by separate warranties of the individual manufacturers of such components (such as appliances, awnings, jacks & jack motors and windows) on its new recreational vehicles. If such parts are found to be defective in factory materials or workmanship made or supplied by the manufacturer. Most of these manufacturers have service centers throughout North America and their warranty information is included in the black document pouch.

This warranty is effective for twelve (12) months from the date of purchase by the original owner and warranty is nontransferable. This warranty does not cover any defects which are not immediately and properly reported as required herein. This warranty does not apply to the cost of transporting materials or the Recreational vehicle to or from the repair site.

This warranty also includes a six (6) year structural integrity warranty which becomes void by lack of regular maintenance, abuse, incorrect tie downs, neglect, alterations, modifications, accidents or misuse. All fiberglass repairs must be done with approved gel coat not automotive paint. All warranty repairs must have preauthorization prior to executing any warranty repairs. Any declared defects must be brought to the selling dealer or to the manufacturer attention no later than ten (10) days after the discovery of any alleged defects.

This warranty pertains only to new recreational vehicles handled in a normal manner. Any defects which, in the opinion of the manufacturer, have occurred as a result of misuse, acts of God, negligence, causes beyond control of the manufacturer, or alteration to the recreation vehicles are not covered by this warranty. This warranty does not apply to any recreational vehicle placed on rental or used for commercial purposes.

During the term of this warranty, repairs (parts & labour) will be made, at no charge to the customer, using Manufacturer's parts or authorized remanufactured parts.

This warranty becomes valid when the camper is registered online at www.northern-lite.com within (30) days of the date of purchase. The foregoing warranty is the only express warranty on the part of the manufacturer and the selling dealer. You may have other rights which vary by Province or State.

The foregoing express warranty is in substitution for and eliminates all other liabilities of any kind whether arising under statute, in tort, by implication of law and otherwise, including, to the full extent as may be allowed by law, liability for any other representations respecting the vehicle, statutory warranties or implied warranties or conditions as to its merchantability or fitness. Any suggested warranty or condition as to merchantability or fitness is confined to the applicable warranty term as defined herein.

Under no circumstances shall the manufacturer be accountable for loss or damage to the recreation vehicle or its parts, loss of time, inconvenience, business loss, consequential or other damages or any other claims associated to or amounting from any defect in factory materials or workmanship whenever found except as provided for herein.

We at Northern Lite Mfg. LP are continuously striving to improve our products. Changes are made from time to time as they are developed. We are under no obligation to retrofit from these changes to earlier models. The features and specifications are subject to change without notice. Northern Lite Mfg. LP reserves the right to change any components used in production at their discretion.

We trust you will enjoy your new Northern Lite camper. Any success we now enjoy and hope to enjoy in the future will depend on how well we please our valued customers. Thank you for choosing a Northern Lite camper.

Loading Truck Camper

One of the most important aspects of owning a truck camper is learning how to correctly load and secure your truck camper to your truck. When loading gear into your camper, always try to keep the load even left to right. As well place heavier items forward of your trucks axle inside the camper.

Always ensure your truck has enough payload capacity to safely carry your camper. The dry weight of your camper is posted in the rear closet as weighed when it left the factory.


Tie downs and Turn buckles

We recommend the use of frame mounted tie downs and spring loaded turn buckles to secure your camper to your truck. All four tie downs locations must be used and turn buckles should be checked regularly for correct tension as driving with loose turn buckles can cause damage to your truck camper. We recommend using TorkLift frame mounts on your truck and TorkLift Fastguns for tie downs on the camper. The black O-ring on a Fast gun should come down 1/4" – 3/8" when tightened correctly.

Mat

We recommend the use of a soft rubber bed mat (3/8") max thickness be installed directly under the bottom of every camper. This helps prevent the camper from sliding in the box. Thicker horse stall type mats do not work as well and will cause the camper to move.

Your camper should be installed on a flat surface and fifth wheel hitches must be removed. If additional height is required we recommend using plywood cut to the length of your box with the 3/8" soft mat installed on top of the plywood. Every Northern Lite truck camper has a center of gravity marker on the left and right side wall. The center of gravity should be within the COG load range found in your trucks Owner's Manual, which on most trucks is forward of the rear axle.



Wiring 7 Way Plug

The 7way plug on all Northern Lite campers is a female plug wired to industry standard 7way flat pin wiring. You will need a male 7way plug from your truck. It is easiest to plug the 7way connector into the camper once you have back under the camper prior to lowering it

| | |
|---------------|--------------------------------------|
| <i>White</i> | <i>Ground – 10 guage</i> |
| <i>Black</i> | <i>Main power 12 volt – 10 guage</i> |
| <i>Green</i> | <i>Clearance light – 16 guage</i> |
| <i>Red</i> | <i>Left signal – 16 guage</i> |
| <i>Brown</i> | <i>Right signal – 16 guage</i> |
| <i>Yellow</i> | <i>Backup – 16 guage</i> |

Batteries

The batteries are supplied and installed by the dealer. We recommend 2 – 12 volt deep cycle batteries in all our campers. 10-2 EX and 8-11 EX models hold 2 – Group 27 batteries. 9-6 Q models hold 2 – Group 24 batteries.

Raising and Lowering Truck Camper

- *Read Happijac camper jack Owner's Manual and Happijac wireless remote camper jack controller manual before operating jacks.*
- *Always load and unload in a level and flat location.*
- *Always keep the front of the camper higher than the rear when raising or lowering.*
- *Use 4"x 4" pieces of 3/4" plywood under each jack on soft ground and asphalt to prevent sinking.*
- *Never raise jacks past red safety line.*
- *Never leave jack unattended with locking lever in down position.*
- *Always disconnect camper tie downs before trying to level camper.*
- *Use extreme caution when windy.*

Dually Swing out Brackets

- *If your camper is equipped with dually swing out brackets it is very important to ensure bracket is swung out and locked before trying to raise camper.*
- *Never raise camper with swing out brackets facing forward, they must be extended out to support weight.*
- *Make sure camper is clear of truck bed by at least 2 inches before pulling truck out. Once truck has been pulled out lower camper as low as the jacks allow, keeping the front 2" higher than the rear.*
- *When putting camper on truck ensure camper is at least 2" higher than the bed of the truck and when backing in stop when campers black bumpers are 3" from end of truck box and level camper, then back up to within 1/2" and lower camper.*
- *Ensure camper bumpers are not getting compressed and pull forward slightly if they are. The bumpers are designed to be torn off if you are attempting to load the camper too far forward.*
- *Keep your wireless remote in a safe dry location when not in use.*
- *The control module for your electric jacks is located in the driver's side rear dump valve area. The electric jacks bypass the camper battery disconnect switch and power runs from the battery, through an auto resetting 40 amp breaker and directly to the electric jack controller module.*

Camper Storage

Your camper is designed to be stored on the jacks. We recommend 4"x 4" pieces of ¾" plywood under each jack pad. The camper should never be left in the air with the jacks fully extended. Always lower the camper as low as the jacks will allow and keep the front 2" higher than the rear. If you choose to add additional support using blocks or saw horses, you must have a full ¾" sheet of plywood between the bottom of the camper and the blocks or saw horses so that the weight is evenly distributed. Failing to do this may result in damage to your camper. Always store camper level left to right with the front higher than the rear.

Camping off the Truck

When using your Northern Lite camper off the truck it needs to be in a flat and level location. You should lower the camper as low to the ground as the jacks will allow, keeping the front higher than the rear. The steps can be used in the stowed position as there is nonskid on both sides of the steps.

Long term usage

RV's are not designed for long term continuous usage. If you are going to use your camper for extended periods it is very important to control the moisture in your unit in both winter and summer in high humidity areas. In winter always use your stove exhaust fan when cooking and run for extended periods afterwards to remove all extra moisture from cooking. Always run the bathroom fan after showering until the shower is dry. Keeping the heat at a steady temperature and not setting back at night will help keep moisture down. We recommend maintaining 74F degrees in the winter. It is important to vent the camper during winter use using a roof vent or window. During summer in high humidity areas your air conditioner will help lower the humidity when in cooling mode. In some areas during winter and summer extended stays you may also require a dehumidifier to maintain the humidity levels in your camper.

Before moving Camper

Each trip before moving your camper

- *Ensure all windows are closed and levers are in locked position. Failure to do this will result in window damage and possibly the loss of the window lens.*
- *Ensure Heki Skylight is closed and latch.*
- *Ensure TV arm is retracted and extra lock pin is in place.*
- *Ensure bathroom door is closed and latched.*
- *Ensure table lock is tightened to prevent table from sliding back and forth.*
- *Ensure all drawers are pushed in and latched in place.*
- *Always lower glass stove top cover prior to moving camper.*
- *Ensure fridge doors are securely closed.*
- *Ensure tie downs are in place*
- *Ensure jacks are raised*

SYSTEMS

Propane – LPG

The propane tanks in your new camper come pre purged so they are ready to fill. Following all safety warnings in the compartment that holds your propane tanks.

- *Always remove tanks to fill*
- ***Never*** *fill past 80% capacity as overfilling can cause the safety device to release pressure by discharging gas.*
- ***Never*** *place or store propane tanks inside you camper or vehicle.*
- ***Never*** *fill with Natural Gas.*

If you smell Gas:

- 1) Extinguish any open flame and pilot light.*
- 2) **Do not** touch electrical switches.*
- 3) Shut off gas supply at tanks.*
- 4) Open windows and doors.*
- 5) Leave area*
- 6) Have system checked by qualified RV Gas Technician.*

Operating Propane System

Your camper is equipped with an auto change propane regulator. We recommend keeping the arrow towards the outside propane tank and refilling when the regulator turns red. It is easier to change the tank closest to the door.

Always open both tank valves slowly as they are QCC Type 1 which has an excess flow safety devices built into them. They need to be hand tight for gas to flow. If you open the tank valves too quickly it will stop the flow of gas.

Your fridge, stove, furnace and hot water heater all run on propane. Thoroughly read the manufacturers manuals before operating any of the appliances. You will find these manuals included in the black pouch.

Fridge

Every Northern Lite truck camper comes equipped with a 3 way fridge and will run on DC, AC and propane. The fridge needs a properly charged battery to operate correctly. When in a campground or home and plugged into 120 volt power, use AC. When travelling use propane and when you travel on a ferry where you need to turn off the gas, we recommend you use the 12 volt DC mode. To work correctly the fridge must be level.

See Fridge Manual for further information

Furnace

Your furnace has two separate heat ducts which run into the basement to heat your tanks and basement area when furnace is running. In below freezing temperatures we recommend keeping your thermostat set to at least 74 degrees Fahrenheit. In extreme cold turn on dump valve light for additional heat.

See Furnace Instructional Manual for safety and operational instructions.

Stove Top/Oven

Never use your cooking appliances for comfort heating. Always use your range hood exhaust fan and open an overhead vent or window, as cooking appliances need fresh air for safe operation.

See your Range Top/Oven Manual for safe operation instructions.

Never use portable fuel burning equipment inside your truck camper as this may cause fire or asphyxiation.

Never light the stove top with the range cover closed. Always have the stove top cover lifted and locked before lighting burners.

****Warning – When refueling or parked near gasoline pumps always shut off all LP Gas appliances.***

Plumbing System

Every Northern Lite camper is equipped with two means of operation for the water system. One when connected to an externally pressurized (city water) water system and one when using the onboard fresh water tank and 12v pump.

City Water Connection

This allows a direct connection to an outside source like a campground or city water at home. This system bypasses the onboard fresh tank and 12 volt pump. When using this connection never turn your pump on and open both hot and cold taps to eliminate any air. A pressure regulator is recommended in areas with unknown water pressure levels to protect the system. When not connected to the pressure system always replaces the cap.

When using the onboard fresh water tank and 12 volt pump, always make sure there is water in your tank and the valves are set for summer use. (See winterizing information on proper valve positions) The pump will turn on and off automatically with the opening and closing of the taps. Never turn on pump if fresh water tank is empty. The pump switch is located on the monitor panel on the dinette wall.

Filling Water Tank

Using the gravity water fill open the cover and insert a garden hose. Fill tank until water comes out the over flow, this will mean your tank is full. If not using water for more than a week the tank should be drained.

Fresh Tank Maintenance

At the beginning of every season it is recommended to add ½ cup of bleach to a full water tank and let it sit for 3 hours, and then pump out by opening all the hot and cold taps one at a time. This ensures your entire system will be sanitized. Flush system until bleach odor is gone. Adding a teaspoon of bleach after any extended periods of usage will help keep the system clean. For draining the water tank and system see chapter on winterization.

Plumbing System (cont'd)

Waste Tanks

The drain handle for the black waste tank is located at the driver's side rear of the camper and is a 3" valve. Connect your sewer hose to the connection under the camper and ensure other end is in a sani dump. Slowly open valve and let drain. Once drained open the smaller grey tank drain valve, this valve is 1 ½". The grey tank will drain faster if the front of the vehicle is higher than the rear. By doing the grey tank second it will clean the black waste out of your sewer hose. Once done remember to close both valves and after disconnecting and rinsing your sewer hose, install the drain cap to the camper sewer connection. Every camper is shipped with a sewer hose connector that will fit inside the bumper. Always use a waste tank deodorizer to reduce holding tank odors.

Hot Water Heater

Always ensure there is water in the water heater and that the valves are in summer mode before turning it on. Always shut the water heater off before draining water. The switch to turn the heater on is located on the kitchen counter face. See Hot Water owner's manual for more information.

Electrical System

120 Volt Power Cord

Your camper comes equipped with a 30' long power cord with a 30amp plug on the end as well as 15amp adapter for plugging your camper in at home and at camp sites. The power cord supplies power to your 45amp converter in the camper which powers your ac circuits to run your optional air conditioner and microwave as well as fridge when plugged into ac. The converter will also charge the batteries in your camper as long as the red battery disconnect switch is turned to the ON position. The converter has a smart 4 stage charging circuit so it does not hurt the batteries if plugged in for an extended period of time. The converter will also run all the 12 volts circuits when plugged in with the exception of the fridge and stereo which are powered directly from the camper batteries.

The 12 volt circuits are protected by automotive type fuses and the 120 volt circuits are protected by house style resettable circuit breakers. There are also GFI (Ground Fault Interrupter) plugs on the kitchen counter and behind the fridge to protect you from electrical shock in damp areas. There should be a green light on the plug if it is working. If there is not green light the plug is tripped and will need to be reset before it will work by pressing the reset button on the face of the plug.

Battery Disconnect Switch

**When using the camper and driving the battery disconnect switch should always be in the ON position. Your batteries can only charge if the switch is in the ON position from the truck or power converter. To test if your truck is charging your camper batteries, Start your truck and turn the battery disconnect switch to OFF then turn on an inside light. If it works then your truck is putting power back to the camper and charging the battery. If the light does not work, you are not getting power from your truck. Check the 7 way cable and the truck's fuse for the trailer charge circuit.*

When not using camper for more than a couple of days turn the switch to the OFF position.

Safety Systems

Smoke/CO Detector

Every camper comes equipped with a combination smoke and carbon monoxide detector. Test the device after your camper has been in storage, before each trip and once a week during a trip. Replace the batteries at least once a year with two “AA” batteries or when the low battery alarm goes off (will beep once a minute). Test after replacing batteries.

Never disconnect the battery due to nuisance alarms or from cooking. Ventilate the camper and the alarm will stop. Vacuum once a month to keep dust free.

LPG Gas Detector

*Each camper is equipped with a LP Gas detector which is hard wired into the camper’s 12 volt wiring system and is located near the floor under the fridge. This unit will alert you to any potentially dangerous LP Gas that may be present from a defective appliance, gas pipe leak, or incorrectly adjusted appliance burner. In the event the propane detector goes off exit the camper and shut off both propane tanks and ventilate the camper by opening door and windows. **DO NOT** turn any lights on. Have gas system checked by a RV technician before using again.*

Fire Extinguisher

Every camper comes equipped with a Fire Extinguisher mounted off the floor by the rear door. Pull the pin and direct discharge at the base of the fire in a sweeping motion. Once used the fire extinguisher must be refilled or replaced.

Solar Panel

Your camper comes standard with a 100 watt solar panel and a 30amp solar controller. At peak sunshine your panel will charge up to 5amps into your camper’s batteries. The solar panel bypasses the battery disconnect switch so it always charges your battery and the Solar Controller is a smart charger so it won’t overcharge your batteries.

Rear Awning

All Special Edition campers come standard with a power rear awning. The rear awning also has an LED light strip which is operated by the switch beside the power awning switch under the rear closet. Never leave camper unattended with awning extended in case the wind comes up and always retract in windy conditions.

Side Awnings

All Special Edition campers come standard with a manual crank side awning. Use the supplier handle to extend awning. The awning legs are stored at the very front of the awning. You may need a short step ladder to reach the unlock lever on the awning. Side awnings must always use the legs when extended. You can attach them to the camper or have them on the ground. Always retract when windy. See Carefree Owner's Manual for maintenance and operating instructions.

Air Conditioners

Air conditioners come standard on our 10-2 EXCD Special Edition and are optional on all other models. The air conditioners we install are designed to work with portable inverter style Honda 2000 or 2200 generators. If you turn your air conditioner off wait five minutes before turning back on. See Air Conditioner Manual for other operating tips.

Microwave

To operate your microwave you must have a generator running or be plugged into shore power. Always keep cabinet door open when running microwave.

Camper Maintenance

Interior Windows/Heki Skylight

Never clean your windows or skylight using paper towel as it can scratch them. Use a soft microfiber towel and the supplied cleaner. If you do scratch your windows there is a scratch remover kit supplied with each camper. When washing the outside always spray windows first to ensure no grit or grime is left on them and use a clean soapy brush to gently clean window. Always spray brush with water first to ensure there is nothing in the brush that may scratch the windows. Always ensure windows are closed and latches are in locked position prior to moving camper.

Fabric

Seat cushions are foam backed and can be professionally cleaned if needed.

Ceiling

If you get a stain on your ceiling fabric use a carpet spot cleaner to gently clean the area.

Exterior Maintenance

The exterior of your camper is a high end Marine Gel Coat and should be washed regularly with mild soap and water. Waxing the front of the camper using a quality Fiberglass boat wax will make removing bugs and road grime easier.

Wax the jack legs every 6 months to prevent rusting. If you are driving in winter, clean jacks regularly to keep road salt and calcium off the jacks.

Check roof coating and sealants every six months. If there is any peeling or lifting scrape off any loose sealant and reapply.

Camper Maintenance (cont'd)

Sealant Used

| | |
|--|--|
| <i>Around roof vents</i> | <i>Heng's white Alkyd Fibered Roof Coat or Dicor Lap Sealant</i> |
| <i>Around solar brackets and TV antennas</i> | <i>Dicor Lap Sealant</i> |
| <i>Around all doors, lights, Windows & center trim</i> | <i>Proflex RV or 3MUV4000</i> |
| <i>To reseal the inside of the Plastic boxes</i> | <i>Proflex RV</i> |

A large, light gray background illustration of two ducks in flight, spanning most of the page. The ducks are shown from a side profile, with their wings spread wide, flying towards the left.

WINTERIZING PROCEDURES


10-2 EX DRY AND WET BATH

WINTERIZATION STEPS.

1. Drain black and gray tanks ,G&H
2. Drain fresh tank. Open valve “C” on (Fig# 2) and leave open, shown open in (Fig#2)
3. Open cold low point drain valve “D” (Fig#2) close, once drained, shown closed in (Fig#2)
4. Open hot low point valve “E” Fig#2 close once drained. Shown closed in (Fig #2)
5. Close valve “I” water tank supply (Fig #1) shown closed
6. Open valve “J” and remove cap “F” and connect clear flex line (Fig#6)and put other end into 1 gallon jug of RV Antifreeze (Fig#7).
7. By Pass hot water tank (Fig #4) close valve “A & “B” for winter (Fig#4) Open valve “C” for winter (Fig#4).
8. Drain hot water tank from outside by removing white plastic drain plug, open pressure relief valve when draining (Fig#5)
9. Turn water pump on and turn kitchen faucet on hot then cold until antifreeze comes out . In bathroom turn each tap on until antifreezes comes out and then pull up shower diverter until antifreeze comes out shower end. Flush toilet until antifreeze comes out. Turn outside shower on cold first until antifreeze comes out then hot until antifreeze comes out
10. Pour 1 cup of antifreeze down each drain including the floor drain in the shower
11. Your unit is winterized now



10-2 EX WET



HOT WATER TANK BY PASS FOR WINTERIZATION

TO ACCESS REMOVE PANEL UNDER BENCH SEAT CLOSEST TO CAB OVER BED

VALVE "A" CLOSE FOR WINTER OPEN FOR SUMMER

VALVE "B" OPEN FOR WINTER CLOSE FOR SUMMER

VALVE "C" CLOSE FOR WINTER OPEN FOR SUMMER




FIG #4

CAUTION: Never drain the water heater when it's hot or under pressure. With no water hooked up the water pump off, open a hot-water faucet to remove any pressure on the system. Allow the tank to cool before draining

FIG#5



WINTERIZATION CLEAR FLEX LINE SUPPLIED WITH CAMPER

FIG#6



**2ND END OF THE CLEAR FLEX LINE, IN ANTIFREEZE BOTTLE.
YOU REQUIRE 1 GALLON FOR THIS UNIT**



FIG#7

A large, light gray illustration of a swan in flight, serving as a background for the central text. The swan is shown from a side profile, with its wings spread wide and its head turned back.

WINTERIZING PROCEDURES

8-11 EX DRY & WET BATH


9-6 WET BATH

WINTERIZATION STEPS.

1. Drain fresh tank. Open valve “C” on (Fig# 2) and leave open, shown closed in (Fig#2)
2. Open cold low point drain valve “D” (Fig#2) close, once drained, shown closed in (Fig#2)
3. Open hot low point valve “E” Fig#2 close once drained. Shown closed in (Fig #2)
4. Open valve “B” hot water tank supply (Fig #4) shown open
5. Close valve “A” & “C” and remove cap “F” See FIG #3 and connect clear flex line (Fig#6)and put other end into 1 gallon jug of RV Antifreeze (Fig#7). Close valve “I” open “J”
6. By Pass hot water tank (Fig #4) close valve “A” & “C” for winter (Fig#4) Open valve “B” for winter (Fig#4).
7. Drain hot water tank from outside by removing white plastic drain plug, open pressure relief valve when draining (Fig#5)
8. Turn water pump on at monitor panel and turn kitchen faucet on, hot then cold until antifreeze comes out . In bathroom turn each tap on until antifreezes comes out and then pull up shower diverter until antifreeze comes out shower end. Flush toilet until antifreeze comes out. Turn outside shower on cold first until antifreeze comes out then hot until antifreeze comes out
9. Pour 1 cup of antifreeze down each drain including the floor drain in the shower
10. Drain black and gray tanks
11. Your unit is winterized now

8-11 EX DRY BATH DRIVER SIDE REAR

| | |
|---|--|
| C | FRESH TANK DRAIN WINTER OPEN SUMMER CLOSE |
| D | COLD LOW POINT DRAIN OPEN TO DRAIN FOR WINTER THEN CLOSE ONCE DRAINED FOR SUMMER KEEP CLOSED |
| E | OPEN HOT LOW POINT DRAIN THEN CLOSE ONCE DRAINED FOR SUMMER KEEP CLOSED |
| G | GRAY TANK DRAIN |
| H | BLACK TANK DRAIN |



| | |
|----------|---|
| C | FRESH TANK DRAIN WINTER OPEN SUMMER CLOSE |
| D | COLD LOW POINT DRAIN OPEN TO DRAIN FOR WINTER THEN CLOSE ONCE DRAINED FOR SUMMER KEEP CLOSED |
| E | OPEN HOT LOW POINT DRAIN THEN CLOSE ONCE DRAINED FOR SUMMER KEEP CLOSED |
| G | GRAY TANK DRAIN |
| H | BLACK TANK DRAIN |



9-6 DRIVER SIDE REAR

| | |
|---|--|
| C | FRESH TANK DRAIN WINTER OPEN SUMMER CLOSE |
| D | COLD LOW POINT DRAIN OPEN TO DRAIN FOR WINTER THEN CLOSE ONCE DRAINED FOR SUMMER KEEP CLOSED |
| E | OPEN HOT LOW POINT DRAIN THEN CLOSE ONCE DRAINED FOR SUMMER KEEP CLOSED |
| G | GRAY TANK DRAIN |
| H | BLACK TANK DRAIN |



CAUTION: Never drain the water heater when it's hot or under pressure. With no water hooked up the water pump off, open a hot-water faucet to remove any pressure on the system. Allow the tank to cool before draining

FIG#5



LOCATION UNDER THE BENCH



HOT WATER TANK BY PASS FOR WINTERIZATION

TO ACCESS REMOVE PANEL UNDER BENCH SEAT CLOSEST TO CAB OVER BED

VALVE "A" CLOSE FOR WINTER OPEN FOR SUMMER

VALVE "B" OPEN FOR WINTER CLOSE FOR SUMMER

VALVE "C" CLOSE FOR WINTER OPEN FOR SUMMER

VALVE "I" OPEN FOR SUMMER CLOSE FOR WINTER

VALVE "J" OPEN FOR WINTER CLOSE FOR SUMMER






FIG #4



SHOWN IN WINTER MODE

FIG #3

WINTERIZATION CLEAR FLEX LINE SUPPLIED WITH CAMPER



**2ND END OF THE CLEAR FLEX LINE, IN
ANTIFREEZE BOTTLE.
YOU REQUIRE 1 GALLON FOR THIS
UNIT**



Fig #7