# NORTHERN LITE CLOCK INSTRUCTION

### **MAIN FUNCTION**

- 1. Time display (12/24 hour)
- 2. Calendar: 2000 2099 year
- 3. Alarm and Snooze function
- 4. Week displays in 7 languages: English(ENG), German(GER), Italian(ITA), French(FRE), Dutch(DUT), Spanish(SPA), Denmark(DAN)
- 5. Indoor Temperature (Celsius/Fahrenheit)

### TIME SETTING

- In clock mode, hold the "SET" button for 2 seconds to enter time setting mode. Press the "SET" button again to scroll through each setting sequence.
- Setting sequence: 12hr/24hr>hour>minute>year>month>date>week>language
- Press the "UP"/"DOWN" button to adjust your setting.
- Setting mode will exit after 30 seconds of inactivity and the setting will be save automatically.

### **ALARM SETTING**

- In clock mode, hold the "ALARM" button for 2 seconds to enter the alarms setting mode.
- Press the "ALARM" button again to scroll through the setting sequence and press the "UP/DOWN" button to adjust the alarm time.
- Setting sequence: hour>minute
- In clock mode, press the "ALARM" button to turn the alarm function on/off. When the alarm function is activated, the alarm icon will appear on the LCD display.
- When the alarm goes off, the alarm icon will flash. Buzzer will sound for 2 minutes.
- The alarm will stop after 2 minutes if no button is pressed during the alarm. It will repeat at the same time on the next day.
- When the alarm goes off, press the "SNZ/L" button to activate the snooze function. The alarm lcon and the snooze icon (Zz) will flash. The alarm will set off again after 5 minutes.
- To get out of snooze mode, press any button except "SNZ/L".
- Press the "DOWN" button to switch between Celsius/Fahrenheit

## TO TURN ON THE LIGHT OF THE DISPLAY

- Press the "SNZ/L" button to illuminate the LCD display.

#### HOW TO REPLACE THE BATTERY

- Open the battery compartment door at the back of the clock, replace with 2 new AA batteries. **NOTE:** When the display is fading, please replace the batteries