

30. Heki Midi Skylight

Your Northern Lite camper is equipped with the **Heki Midi Skylight**, providing natural light and ventilation to enhance your camping experience.

Features:

- Large skylight opening for increased airflow and natural light.
- Integrated roller blind for shade and privacy.
- Built-in insect screen to keep bugs out.
- Secure locking system to prevent accidental opening during travel.

Operation:

Opening and Closing the Skylight:

- Press the release button (2) and open the skylight with the bar (1) at the same time.

Opening the Skylight Fully

- Slide the Bar/Bracket (2) into the (i) position

Opening the Skylight Half-way

- Slide the Bar/Bracket (2) into the (ii) position

Opening the Skylight to provide continuous ventilation

- Slide the Bar/Bracket (2) into the (iii) position so that it clicks into the locking position at the back.

Closing the Skylight

- Slide the Bar/Bracket (2) into the (iv) position
- Guide the bracket (2) with slight pressure from left and right via the (3) catches so that the skylight lid is locked into place and the Bar/Bracket (2) until it clicks into the closed position
- Ensure that the skylight is fully locked before travel.

Using the Blind and Screen:

- Pull the **roller blind** across for shade and privacy.
- Slide the **insect screen** into place to prevent bugs from entering.

User information for your Midi-Heki skylight can be found at the following link. Midi-Heki [Dometic Midi Heki FL - Installation and Operating Manual EMEA14-APAC1](#) User guide

Safety Considerations:

- Always ensure the skylight is closed and locked before driving.
- Do not force the skylight open if resistance is felt.
- Keep the insect screen clean to maintain proper airflow.
- **NEVER travel with the Midi Heki in the open position**

