

This document will outline how to operate and safely store the table in a face-to-face dinette when not in use.

The table in a face-to-face dinette can be adjusted vertically and horizontally.



To adjust the table from the upright position to the bed position the vertical adjustment latch must be twisted clockwise to the unlatched position shown.





Face to Face Table Operation Service Bulletin

Revision: 01

Effective Date: 8 Oct 26

Revision Date: N/A

To adjust the table horizontally the knob must be rotated clockwise to unlock the slide. The table can then slide left or right as needed.



When the camper is not in use, the table should be stored in the upright position with the vertical and horizontal adjustments locked.

